



Fitness Tracker User Guide



Please read the manual before use.

Disclaimer

CO-PILOT has made every effort to ensure that all the information contained in this manual is accurate and reliable. However, the information is subject to change without notice.

CO-PILOT assumes no responsibility for any damage or injury resulting from the use of this product.

No part of this publication may be copied, distributed, transmitted or transcribed without the permission of CO-PILOT.

Warranty and Registration

Your CO-PILOT device is guaranteed for one year from the date of purchase from all manufacturing defects that occur with normal use. If your unit fails to perform as specified in this user guide please contact your retailer or ourselves with regards to your warranty. To activate the 12 month warranty please visit www.copilotmobile.co.uk.

- ◆ **Product components**


1. Wristband
2. Fastener
3. OLED screen
4. Red circle

- ◆ **Installing the app“DayDay Band”on your smartphone**

To download the app on your Smartphone, scan the QR code printed in the device’s box or look for the“DayDay Band”app in the Google Play Store for Android devices or the App Store for iOS devices.

- ◆ **Charging the Fitness Tracker**

When the low-battery icon displays, charge the Fitness Tracker by removing it from the wristband where it is placed. Then connect it to a USB port using the supplied cable as described below. Connect the cable to a USB port to begin the charge.



◆ Using the Fitness Tracker

1. ON/OFF:

Touch the red circle and hold it for 3 seconds. The Fitness Tracker will power on. To turn it off hold the red circle for 3 seconds. A message with ON and OFF option will appear. Touch the red circle to select OFF and then touch it again and hold it until the Fitness Tracker turns off.

2. Connecting to the Fitness Tracker

The first time you link your Fitness Tracker with a device, with the bracelet on, open the app and after the notifications it will look for your device. You can also enter the option “Add device”. Select your Fitness

Tracker when it appears between the available devices. When the connection is ready, the Bluetooth logo will display in the Fitness Tracker permanently. During the connection the Bluetooth icon in the Fitness Tracker will blink.

On Android devices, you can select in the app the notifications you want to receive.

On IOS devices, if you want to receive notification alarms on your Fitness Tracker, use the app“DayDay Band”on your phone. A new Bluetooth link will be requested which you must accept. From that moment on, you can select in the app the notifications you want to receive. Once connected, you can press the red circle to switch between the different data that the Fitness Tracker provides: Steps, Distance and Calories burned.

◆ Functions

1. Time, steps, distance, calories burned measurement, heart rate
2. Intelligent alarm, intelligent anti lost function.
3. Take photos by pushing the red circle or shaking the Fitness Tracker.
4. Receipt of notification alarms.

◆ Technical Specifications

Battery: 40mAh Lithium polymer

Compatible with: Android 4.3, IOS 9.0 or higher / Bluetooth 4.0

Waterproof: IP65 (no deeper than 1m)

Band length and adjustable length: 225 mm, 157-205mm.

Weight: 7g

Working temperature: -10°C–50°C

Wristband material: ABS and aluminum alloy.

◆ Notes before use

1. Avoid prolonged exposure to water, do not immerse deeper than 1m.
2. Do not disassemble or alter the device's battery.
3. Use the original provided cable to charge and synchronize the Fitness Tracker.
4. If the Fitness Tracker crashes, please clear the APP information and try again (on IOS devices, go to the Bluetooth settings and select “delete device from history”)
5. Do not expose the device to direct sunlight, extreme heat or cold, damp or dusty conditions.

Co Pilot contact details:

Address: In Phase International Ltd, 3A Rani Drive, Nottingham, Nottinghamshire, NG5 1RF

Phone: 0330 123 9040

Web: www.copilotmobile.com

Email: contact@copilotmobile.co.uk