



Smart Watch Plus User Guide



Please read the manual before use.

Disclaimer

CO-PILOT has made every effort to ensure that all the information contained in this manual is accurate and reliable. However, the information is subject to change without notice.

CO-PILOT assumes no responsibility for any damage or injury resulting from the use of this product.

No part of this publication may be copied, distributed, transmitted or transcribed without the permission of CO-PILOT.

Warranty and Registration

Your CO-PILOT device is guaranteed for one year from the date of purchase from all manufacturing defects that occur with normal use. If your unit fails to perform as specified in this user guide please contact your retailer or ourselves with regards to your warranty. To activate the 12 month warranty please visit www.copilotmobile.co.uk.

1. Safety Warning

- ◆ The information in this document won't be modified or extended in accordance with any notice.
- ◆ The watch should be charging 2 hours at least before use
- ◆ The original code is 1122. This code can prevent your watch in use by others without your permission.
- ◆ Please change the original code to insure your personal information safe.

2. Product details:

2.1. Product details

Power button: Long press to power On/Off; Short press to awake/dark screen/ back to main menu

USB port: Charging/Data:

Touch screen: each function will be shown and displayed on the touch screen.

2.2. Screen

You can enter into next page by sliding screen to the left, and return to last page by sliding screen right; It is will be in mistake for a click if the drag distance too short.

2.3. Clock Display (the following picture is for reference only, goods in kind prevail)



Setting method:

Method 1: Power on, when the phone is in clock mode, please click middle screen and set different clock interfaces to your preference.

Method 2: Power on, Main menu: setting—phone setting—standby menu display—unlock selection, choose the clock mode to your preference.

3. Product quick use

3.1. Download the Sync software.

Scan QR code, down load the APP which can match your phone, This APP is only for the Sync between watch and phone, will not take your phone GPRS.

If you already download the related software, please check the version and use the newest related in order to ensure all functions run normally. Please update the software when it has a new version.

3.2. Install and use the Sync software

Android Application installation:

Please install the android application in your smart phone, you can store it into your phone memory or install by Sync assistant.

Android application usage (already installed)

(Smart phone) Setting—Accessibility—Enter into Bluetooth notice (service), enable this service. The application runs on the background automatically and sync function will be switched on as below:



Click the Bluetooth notices and choose the Notification service, select your Personal or System application in Notify application. Telephone service is including SMS, incoming call and seek watch.

Notice:

Please don't shut the Bluetooth notify service when you are clearing software or closing background application software. It will affect the Sync function between watch and phone.

3.3. Bluetooth Connection and Sync function

3.3.1. From phone to watch

Phone setting—turn on Bluetooth—search for devices, please click pair devices when found W90 and also choose “yes” in your mobile phone which will than pair the two devices.

Please choose “sure” when there is a phone book request. Meanwhile you’d better choose “no remind again”, this is convenience when you connect next time (without remind again). Notice: the Sync software can open in sync APP already installed and Accessibility, the mobile will show Bluetooth connected after 2-5 min; the watch will inform you the time of Sync with your phone. The message will sync to your watch when it is incoming to your mobile.

3.3.2. From watch to phone

BT dialer on Smart watch ---Search new device—found your smart watch (such as s9500)—connect. The processes of next are same with 3.3.1

3.4 Base function

3.4.1 Message

Sync phone or watch message.

3.4.2 Bluetooth

Sets the Bluetooth status, turn on/off.

3.4.3 Calls records

You can check your phone call records after you connect with the Bluetooth.

Shown all records including miss call, dialed calls and receive call; you can check the date, time and phone number of the miss call after you choose it. But only can call this number.

3.4.4 BT dialer

Paired devices from smart watch

3.4.5 Remote notifier (Only for Android users)

When there is SMS, incoming messages from QQ and other applications

on the connected phone, the watch will alert you to read them.

3.4.6 Remote cameras

Smart watch camera can control smart phone camera.

3.4.7 Anti lost

Watch seek phone, or phone seek watch.

3.4.8 Setting

Notice: sets clock display and theme in phone setting. In the security settings. The safe code is 1122.

3.4.9 Pedometer

It can be adopted as a tool to avoid insufficient or excessive exercise by measuring calories consumption based on collected data, such as number of steps, distance, speed time, etc. to control exercise.

If you want return to main menu but keep pedometer during the exercise. Please press the power button.

3.4.10 Sleep monitor

Show your sleep quality based on your sleep times.

3.4.11 Sedentary remind

You can set a time to remind you to exercise

3.4.12 Quick response

It can download the sync software when you scan the quick response, if there is a new version you need to update.

3.4.13 Alarm

3.4.14 Calendar

3.4.15 Calculator

3.4.16 Profiles

3.4.17 File manager

3.4.18 Audio player

Can play music from your smart phone after connected via Bluetooth.

3.4.19 Camera

3.4.20 pictures

3.4.21 Recorder

3.4.22 QQ: Need to insert SIM card first and SIM card have GPRS.

3.4.23 Browser

When your phone has SIM card you can use the Internet.

4. Notice

Main menu: Theme setting, choose the theme of your preference.

- 4.1.** Full charge before use, the charge time needs to be 2 hours.
- 4.2.** Use the accessories cable and charger.
- 4.3.** Bluetooth will disconnect when you have exceeded the distance, after switch on the Anti-lost. The smart search function can't be used before you have reconnected with Bluetooth.
- 4.4.** Please reconnect with Bluetooth if it's disconnected repeatedly (please manual connect if the Bluetooth is disconnected for over 5 minutes).
- 4.5.** When playing music, some of music's name can be shown and some can't, it is normal.

5. Common trouble shooting

Please refer below key functions for any problems with the watch, if the problem is still unsolved, please contact us.

- 5.1.** Unable to switch on

Hold power button for more than 3 seconds

Low power, please charge it.

5.2. Shut down automatically

Low power, please charge it.

5.3. Using time too short.

Battery is not full, please make sure it is full power (full charge need 2hours at least).

During the use of SIM card, the power will not last as long if the signal too poor.

5.4. Unable to charge.

Charging cable may need to be replaced

Please check the USB slot is connected properly

5.5. No caller's name when incoming call

Upload the phone book when connected with Bluetooth.

Forgot to sync the phone book when reconnected, please pair the device and connect Bluetooth again.

5.6. Bad phone call voice

Watch and phone are separated too far, please be closer;

Co Pilot contact details:

Address: In Phase International Ltd, 3A Rani Drive, Nottingham, Nottinghamshire, NG5 1RF

Phone: 0330 123 9040

Web: www.copilotmobile.com

Email: contact@copilotmobile.co.uk